



• **Stock for exchange**

• **Large inventory – FAA Certified**



Part Number	Description
Avionics	
622-9818-751	MAINTENANCE COMPUTER, DIAGNOSTIC
Electrical	
1134104-5	MOTOR
1134104-5	MOTOR
1134104-5	MOTOR
128-364122-7	ROLL TRIM PC BOARD
128-364122-7	ROLL TRIM PC BOARD
23080-050	STARTER GENERATOR
23080-050	STARTER GENERATOR
23080-050	STARTER GENERATOR
23080-050	STARTER GENERATOR
51539-006J	GENERATOR CONTROL UNIT
51539-006J	GENERATOR CONTROL UNIT
87-5106-2	POWER SUPPLY
87-5106-2	POWER SUPPLY
87-5106-2	POWER SUPPLY
PC820-133	SIGNAL CONDITIONER
Environmental	
102466-15	REGULATOR, AIR PRESS
102466-15	REGULATOR, AIR PRESS
103570-27	VALVE, OUTFLOW
130356-9	CONTROLLER, PRESSURIZATION
130358-3	PNEUMATIC RELAY
130358-3	PNEUMATIC RELAY
1895-00-1	PRESS REGULATOR VALVE
1895-00-1	PRESS REGULATOR VALVE
1896-00-3	VALVE, PRESS REGULATING
1896-00-3	VALVE, PRESS REGULATING
979494-1	PRESSURE SHUTOFF VALVE
979494-4	PRESSURE SHUTOFF VALVE
979494-4	PRESSURE SHUTOFF VALVE
Fire & Ice	
3033057	ANTI ICE VALVE
3033057	ANTI ICE VALVE

Part Number	Description
3033057	ANTI ICE VALVE
30400018-3	FIRE EXTINGUISHER W/SQUIBS
Flight Controls	
100-TA1966-N4	FLAP POSITION TRANS
100-TA1968-N10	FLAP FOLLOW UP
100-TA1968-N10	FLAP FOLLOW UP
100-TA1968-N10	FLAP FOLLOW UP
100-TA1968-N10	FLAP FOLLOW UP
100-TA1968-N10	FLAP FOLLOW UP
100-TA1968-N11	FLAP FOLLOW UP
100-TA1968-N11	FLAP FOLLOW UP
100-TA1968-N11	FLAP FOLLOW UP
100-TA1968-N11	FLAP FOLLOW UP
45AS61014-108	ACTUATOR, RIGHT ROLL TRIM
AA-34-12M1	ACTUATOR, LEFT ROLL TRIM
AA-34-13M1	ACTUATOR, RUDDER TRIM
AA-34-14M1	ACTUATOR, RUDDER TRIM
Fuel	
10140T01Y00	FUEL PROBE
10140T01Y00	FUEL PROBE
EM4018-3	FUEL SHUTOFF VALVE
EM4018-3	FUEL SHUTOFF VALVE
EM4019-2	FUEL SHUTOFF VALVE
Hydraulics	
PV3-022-25	PUMP, HYDRAULIC
Instrumentation	
100-TA1964-N8B	STAB TRIM INDICATOR
10450-11525	ENCODING ALTIMETER
1611AM10	STANDBY ALTIMETER
501-1412-03	STANDBY GYRO
501-1412-03	STANDBY GYRO
9053-3023	FUEL INDICATOR TEMP
M888	DIGITAL CLOCK
M888	DIGITAL CLOCK
SEL-OC19BT-2	INDICATOR, ITT
SEL-OC19BT-2	INDICATOR, ITT

Part Number	Description
Landing Gear	
128-820044-1	DRAG STRUT NLG
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
400-8002-97	BRAKE ASSEMBLY
45100-41	SHIMMY DAMPNER, NLG INCR STEERING
45100-41	SHIMMY DAMPNER, NLG INCR STEERING
45100-41	SHIMMY DAMPNER, NLG INCR STEERING
Lighting	
45AS88830-007	LANDING LIGHT ACTUATOR
45AS88830-007	LANDING LIGHT ACTUATOR
Oxygen	
MC10-15-18	MASK, CREW OXYGEN
MC10-15-18	MASK, CREW OXYGEN
MC10-15-18	MASK, CREW OXYGEN
Pneumatic	
23111321-1	PNU RESERVOIR W/OUT GAUGE
23111321-1	PNU RESERVOIR W/OUT GAUGE
23111321-1	PNU RESERVOIR W/OUT GAUGE
23111321-1	PNU RESERVOIR W/OUT GAUGE
23111321-1	PNU RESERVOIR W/OUT GAUGE
23111321-1	PNU RESERVOIR W/OUT GAUGE
Powerplant	
68620	ACTUATOR, THRUST REVERSER
68620	ACTUATOR, THRUST REVERSER
68620	ACTUATOR, THRUST REVERSER
68620	ACTUATOR, THRUST REVERSER
68620	ACTUATOR, THRUST REVERSER
68620	ACTUATOR, THRUST REVERSER